


## SAFE WORKING LOADS HYDRAULIC OPERATION

#### LOADED CONCENTRICALLY AND 1° MAX OUT OF PLUMB



### NEVER EXCEED SAFE WORKING LOADS

- i) Safe Working Loads have been derived from load testing to BS EN 1065.
- ii) Hydraulic Safe Working Loads are calculated to a minimum Factor of Safety of 2.5 to 1 on test results.
- iii) Convert kg to kN: 10 kg = 0.09807 kN. e.g. 100 kg = 0.9807 kN, 1000 kg = 9.807 kN, 5000 kg = 49.04 kN.

### COMPREHENSIVE USER INSTRUCTIONS AVAILABLE AT UNI-PROP.COM



# SAFE WORKING LOADS MECHANICAL OPERATION

#### LOADED CONCENTRICALLY AND 1° MAX OUT OF PLUMB



## **NEVER EXCEED SAFE WORKING LOADS**

- i) Safe Working Loads have been derived from load testing to BS EN 1065.
- ii) Mechanical Safe Working Loads are calculated to a minimum Factor of Safety of 2 to 1 on test results.
- iii) Convert kg to kN: 10kg = 0.09807kN. e.g. 100kg = 0.9807kN, 1000kg = 9.807kN, 5000kg = 49.04kN.

COMPREHENSIVE USER INSTRUCTIONS AVAILABLE AT UNI-PROP.COM