





### FOR OPERATION WITH UNI-PROP ACROW










































# **QUICK START GUIDE**UNI-PROP<sup>®</sup> HYDRAULIC ASSEMBLY FOR OPERATION WITH UNI-PROP ACROW

COMPREHENSIVE USER INSTRUCTIONS AVAILABLE AT UNI-PROP.COM

# **SAFE WORKING LOADS** <u>HYDRAULIC</u> OPERATION

#### LOADED CONCENTRICALLY AND 1° MAX OUT OF PLUMB

**TTAL PROP**®



### **NEVER EXCEED SAFE WORKING LOADS**

i) Safe Working Loads have been derived from load testing to BS EN 1065.

ii) Hydraulic Safe Working Loads are calculated to a minimum Factor of Safety of 2.5 to 1 on test results.

iii) Convert kg to kN: 10kg = 0.09807kN. e.g. 100kg = 0.9807kN, 1000kg = 9.807kN, 5000kg = 49.04kN.

### COMPREHENSIVE USER INSTRUCTIONS AVAILABLE AT UNI-PROP.COM

# UNI-PROP®

## **SAFE WORKING LOADS** <u>MECHANICAL</u> OPERATION

UP-QUI-212-44

### LOADED CONCENTRICALLY AND 1° MAX OUT OF PLUMB



### **NEVER EXCEED SAFE WORKING LOADS**

i) Safe Working Loads have been derived from load testing to BS EN 1065.

ii) Mechanical Safe Working Loads are calculated to a minimum Factor of Safety of 2 to 1 on test results.

iii) Convert kg to kN: 10kg = 0.09807kN. e.g. 100kg = 0.9807kN, 1000kg = 9.807kN, 5000kg = 49.04kN.

### COMPREHENSIVE USER INSTRUCTIONS AVAILABLE AT UNI-PROP.COM

**Working Load Limit (kg)**